

# Functionality of Arduino MEGA2560 (REV3) Peripheral Circuitry

Thalagala B.P. 180631J

April 29, 2020

The Arduino MEGA2560 is a microcontroller board based on the ATmega2560. It has 54 digital input/output pins (of which 15 can be used as PWM outputs), 16 analog inputs, 4 UARTs (hardware serial ports), a 16 MHz crystal oscillator, a USB connection, a power jack, an ICSP header, and a reset button[1].




Figure 1: Top view of the Arduino MEGA 2560 REV3 board[1]

## 1 Power Regulator Circuit

Power regular circuit is used to regulate the input voltage of the board form a voltage in range of 7V-12V to lower +5V, as this is the operating voltage of the Arduino MEGA board.It consists of following electronic components.




Figure 2: Power regulator schematic diagram[1]

### 1.1 Barrel connector

This barrel type connector is used to supply DC power (6V-12V is recommended) to the board from an external power source.

### 1.2 Reverse Voltage Protection Diode

If the polarity of input supply voltage is accidentally reversed the board may get damaged. This M7 diode (SMD version of 1N4007 diode) provides the protection at such situations.

### 1.3 Electrolytic Capacitors

Polarized capacitors are used to reduce possible small fluctuations (electrical noise) in the input voltage/current. Capacitors with fairly high capacitance (47μF) is used for this purpose as they can store high electric charge.

### 1.4 Non-polarized Capacitors

Although electrolytic capacitors have high capacitance it is considerably slow in discharging process due to its high series resistance (capacitive reactance). As a solution for this draw back,electrolytic capacitor is discharged through a non-polar capacitor with very low capacitance(100nF) and an extremely small discharging time.

### 1.5 LD1117S50CTR Voltage Regulator IC

This IC continues to work although the input voltage is very close to the required output, and able to handle currents up to 800 mA. Also it can regulate voltages in the range 6.5V to 15V to lower 5V level[3].

## 2 Clock Circuit

Micro-controllers use clock signal to trigger events and keep track of time as everything happens with respect to time. clock Circuitry is responsible of generating this clock signal which is basically an electronic signal periodically toggle between two states like a Square wave[5].




Figure 3: External oscillator schematic diagram[1]

## 2.1 Crystal Oscillator

Arduino MEGA 2560 uses 16 MHz oscillator to generate this clock signal. It consists of a *piezoelectric Crystal resonator*[4] and two ceramic capacitors in order to adjust resonance frequency.

## 3 In-system In-circuit Serial Programming/ Programming/ Circuit

Arduino MEGA2560 board has two ICSP headers named as ICSP1 and ICSP. Both headers have 6 pins and are arranged in 2 \* 3 arrays. 6 pins are named as MISO, MOSI, SCK, V+(+5V), Ground, and Reset[2].




Figure 4: ICSP headers in an Arduino MEGA2560 board[1]

### 3.1 ATMEGA16U2 microcontroller

Programs related to USB to serial conversion are stored here. This supports to upload the programs into main ATMEGA2560 microcontroller, simply through the USB cable.

### 3.2 ICSP1

ICSP1 header is used to implement the USB to serial converter micro-controller(*ATMEGA16U2*).

### 3.3 ICSP

ICSP header is used to directly program the main microcontroller of the Arduino MEGA2560 board, whenever the USB to serial converter can not be used to program the microcontroller due to any failure of converter. To do this additional ISP/ICSP programmer(*an electronic circuitry*) is needed.

## 4 Reset Circuit

There are two mechanisms to reset the Arduino MEGA2560 board. One of them is manual while the

other one is done by the USB to serial converter chip. Here the reset pin is *active low*, i.e. microcontroller get reset whenever the pin receives a low state signal.

### 4.1 Manual Method

To reset the microcontroller there is a TS42 type press button switch on the board. When it is pressed, reset pin is grounded. This process resets the microcontroller.




Figure 5: Manual resetting[1]

### 4.2 Reset through the ATMEGA16U2

In this method microcontroller get reset whenever a connection is made with the Arduino IDE through its USB cable. The required DTR(Data Terminal Ready)signal is sent by the ATMEGA16U2 to the RESET pin of the ATMEGA2560 at the beginning of each connecting.




Figure 6: Automatic resetting[1]

## Bibliography

- [1] Arduino Mega 2560 Rev3 | Arduino Official Store. <https://store.arduino.cc/usa/mega-2560-r3>.
- [2] arduino uno - ICSP pin, what is it actually? <https://arduino.stackexchange.com/questions/40098/icsp-pin-what-is-it-actually>.
- [3] LD1117xx Datasheet - STMicroelectronics | DigiKey. <https://www.digikey.com/en/datasheets/stmicroelectronics/stmicroelectronics-en-cd00000544#pdf>.
- [4] Crystal Oscillator : Working and Its Various Applications. <https://www.watelectronics.com/crystal-oscillator-circuit-working-applications/>, September 2019.
- [5] Wikipedia contributors. Electronic oscillator — Wikipedia, the free encyclopedia. [https://en.wikipedia.org/w/index.php?title=Electronic\\_oscillator&oldid=953594751](https://en.wikipedia.org/w/index.php?title=Electronic_oscillator&oldid=953594751), 2020. [Online; accessed 28-April-2020 ].